



# High Productivity, Authentic Quality

HIGH-SPEED  
PRODUCTIVITY

HIGH-DEFINITION  
OUTPUT

ULTIMATE  
VERSATILITY



High speed with the fastest  
flatbed UV printer in its class

- ▶ Staggered print heads, powerful lamps and increased bed size make the MO Series the ultimate in high-production flatbed UV print.
- ▶ Deliver printing speeds up to approximately 1.4 times faster than comparable models from other brands.
- ▶ Twice as fast as previous models when printing white or gloss ink.



Unrivalled print quality with a  
complete solution

- ▶ Specially formulated UV inks deliver high-definition results every time.
- ▶ Reproduce small letters, fine textures, gradations and high-quality graphics with ease.
- ▶ Additional Red and Orange inks extend the colour gamut ensuring accurate colour matching.



Versatile and flexible to  
address any business need

- ▶ Print on a wide variety of substrates and objects with the same powerful ink formulation.
- ▶ Distance Mode makes it possible to print high quality graphics on curved or uneven surfaces.
- ▶ An optional rotary printing unit allows customisation of cylindrical objects.

## Additional Features

- + Included VersaWorks 7 RIP—featuring new True Rich Color 3 preset, Nearest Colour Finder, and Variable Data Printing function.
- + Roland DG Connect App ready—giving you instant access to important data about print jobs as well as your business.
- + A variety of available ink configurations expand your capabilities to include rich colours and interesting spot UV effects.
- + A user-friendly 7" touch screen displays all relevant information making print set-up intuitive and fast.
- + EUV-A Ink offers excellent flexibility, primer-less acrylic printing, and supports thermoforming.

## Technical Specifications

		MO-240	MO-180
Dimensions		1,601 mm × 1,267 mm × 760 mm (63.1 in. × 49.9 in. × 30.0 in.)	1,449 mm × 961 mm × 760 mm (57.1 in. × 37.9 in. × 30.0 in.)
Attachable objects to be printed on	Width	Max. 640 mm (25.1 in.)	Max. 488 mm (19.2 in.)
	Length	Max. 488 mm (19.2 in.)	Max. 335 mm (13.1 in.)
	Thickness	Max. 204 mm (8 in.)	
	Weight	Max. 8 kg (17.6 lb.) (When using a vacuum table: max. 4 kg [8.8 lb.])	
Printing width/printing length (width x length)		Max. 610 mm × 458 mm (24 in. × 18 in.)	Max. 458 mm × 305 mm (18 in. × 12 in.)
Ink	Inks	Eight Colours (Cyan, Magenta, Yellow, Black, Orange, Red, White, Gloss) and, Primer	
	Type	ECO-UV (EUV5P) 750 ml pouch; UV-Ink (EUV-A) 750 ml pouch	
	Configurations	<b>EUV5P</b> CMYKGIWhReOr CMYKWhReOrPr CMYKGIWhRePr CMYKWhWhReOr CMYKGIWhWhPr CMYKGIGIWhWh CMYK  <b>EUV-A</b> CMYKGIGIWhWh	
Control panel		7 in. touchscreen display	
Resolution		Max. 1,200 dpi	
RIP (included)		VersaWorks	

Roland DG reserves the right to make changes in specifications, materials or accessories without notice. Actual output may vary. For optimum output quality, periodic maintenance to critical components may be required. Please contact your Roland DG dealer for details. No guarantee or warranty is implied other than expressly stated. Roland DG shall not be liable for any incidental or consequential damages, whether foreseeable or not, caused by defects in such products. Reproduction or use of copyrighted material is governed by local, national, and international laws. Customers are responsible for observing all applicable laws and are liable for any infringement.

AUTHORISED DEALER:



www.rolanddg.com